



TIRE PRESSURE SYSTEMS

MAINTENANCE SCHEDULE

AT P.M. INTERVALS

1. Check for air leaks in the system.
2. Check condition and fastening of parts on wheel assembly.
3. Check operation of system.

ANNUALLY OR AT EACH 300,000 km

1. Replace rotors.
2. Clean VIGIA air filter.

PLEASE REFER TO YOUR USER'S MANUAL

ORDER ON-LINE

www.vigia.ca / 1-888 438-8444